

KEYLESS TOUCHSCREEN DEADBOLT



MODEL BE375

Locking and Unlocking

From the outside:

To Lock

1. Press the Schlage button.*
2. Rotate the thumbturn away from the hinges.





*If the Lock & Leave feature is disabled, a valid User Code must be entered to lock the door. See [Enable or Disable Lock & Leave](#) on page 12.

ENGLISH

To Unlock

» If lighting is low, press the Schlage button to illuminate the touchscreen numbers before beginning.

1. Enter a User Code into the keypad.
2. Rotate the thumbturn toward the hinges.






Changing the Battery

- » Tip: Replace the batteries in your lock at the same time each year that you test and replace the batteries in your smoke alarms. This will ensure continued reliable operation. Use a high-quality alkaline 9 volt battery for replacement.
- » If your lock's low battery icon is lit, replace the battery as soon as possible.



1. Remove the inside cover.
2. Replace the battery.
3. Re-tuck wires so they will not be crimped. Replace the cover.



ENGLISH



Battery Jump

The emergency battery jump start can be used if your battery is dead to unlock your door. Do not remove the battery until you have opened your door.

WARNING: The lock will remain unlocked until you change the battery or manually relock the door from the inside!

1. Connect a new high-quality alkaline 9 volt battery to the contacts below the touchscreen keypad.
2. Enter a User Code into the keypad.
3. Rotate the thumbturn toward the hinges.

- » Keep the battery connected to the jump start contacts as you unlock your door.



4. Replace the dead battery with the new 9 volt battery. See **Changing the Battery** above.

Lithium Batteries?



Lithium batteries may have a longer life, but when they begin to fail, they fail quickly. We don't recommend them because they don't give you a lot of time to change your batteries before the lock is completely dead.